



Eurovox Wiring Colour Coding

<u>FUNCTION</u>	<u>STANDARD</u>	<u>PRE 1988</u>
ACCESSORY + 12V	RED	RED
BATTERY +12V	PINK	PINK
DIMMER IN + 12V	ORANGE	ORANGE
GROUND	BLACK	BLACK
ANT +12V OUTPUT	GREY	GREY
FRONT LEFT +	GREEN	GREEN
FRONT LEFT -	GREEN/BLACK	BROWN
FRONT RIGHT+	WHITE	WHITE
FRONT RIGHT-	WHITE/BLACK	BROWN
REAR LEFT+	BLUE	BLUE
REAR LEFT-	BLUE/BLACK	BROWN
REAR RIGHT+	YELLOW	YELLOW
REAR RIGHT-	YELLOW/BLACK	BROWN
AMP TRIGGER	YELLOW	N/A
PHONE MUTE	PURPLE	N/A